
TINGMARGID / Symbols
Pressure regime (north, 70 bar) crossing soil
Pressure regime (south, 70 bar) crossing soil