



The diagram illustrates a fault system. A horizontal line represents a fault, with a green box labeled 'SK1' on the left and a pink box labeled 'SK1' on the right. To the right of the pink box is a pink box labeled 'SN1'. A dashed line with arrows indicates a fault segment. A curved arrow indicates a rotation of 231°.

1. Torustike asukoht vt joonis VKV-4-02
2. Tingmärgid vt joonis VKV-4-01
3. Ehituskaeviku tüüpristlõiked vt joonis VKV-6-01

Altren projekt oü